

**Nicoll Industries limited**  
**Professional 40 Spare Parts List**



1. Top Corner Bracket



2. Cross Bar Joining Bracket



3. Corner Pull Pin Bracket



4. Collar and Pin



5. Top Bracket from Middle Leg on  
3M x 6M



6. Sliding Middle Leg Bracket from a  
3M x 6M



7. Upper Mast Pole Lower Mast Pole



8. Mast Sliding Joint



9. Pull Pin



10. Cross Bar Pair



11. Lower Leg



12. Upper Leg