



Nicoll Industries

Important Information

Please make sure that you read these instructions carefully before attempting to erect your marquee for the first time and retain them for future reference.

With the correct care and maintenance this marquee should last you for many years. However, it is not recommended that you attempt to erect or use the marquee in adverse weather conditions, such as strong winds, without taking sensible precautions. We strongly advise that you insure your marquee for accidental damage caused by storms or other forms of damage.

Check the contents of each box against the enclosed packing list and make sure that you have all the necessary parts and are familiar with them before you attempt to erect the marquee for the first time.

This marquee is not guaranteed to be totally waterproof, as some of the seams may not be fully welded due to impracticality. Some leakage may occur around these seams but it shouldn't be excessive or in any way mar your enjoyment of the marquee. You can always obtain cans of sealant from a good tent or outdoor shop and treat any such seams yourself if required.

It is recommended that the marquee be securely fastened down when erected with a suitable tie down kit. You will be able to purchase these from your dealer or the outlet where you purchased the marquee. In extreme circumstances alternative means of fastening the marquee down may be required such as sand bags, ground anchors or heavy weights attached to the frame although, if the weather is that bad, we would strongly advise you either dismantle the marquee or, at least, remove the sides, ends and roof in order to prevent damage which would not, in these circumstances, be covered by the warranty.

Important

Precautions against damage.

Although the marquee is treated to make it flame retardant, IT CAN STILL BURN. Therefore it is vitally important to make sure that any source of heat or flame is kept well away from the marquee.

We suggest that you keep the marquee as far away as possible from any other structures, trees, hedges etc.

Do not erect the marquee underneath or too close to overhead power lines and make sure all entrances and exits are kept clear of obstructions.

When dismantling your marquee carry out the assembly procedure in reverse, making sure that you have help. Thoroughly dry all parts before putting it away as storing it when wet may result in it being damaged by mildew.

The marquee should always be stored in dry, warm conditions where possible and we suggest applying a thin coat of 'Vaseline' to prevent rusting of the frames. If the marquee is dirty it can be cleaned with warm, soapy water. DO NOT USE ABRASIVE OR SPIRIT BASED CLEANING FLUIDS OR COMPOUNDS.

The marquee is not covered by the warranty if these conditions are not adhered to and damage occurs through the marquee being stored in the wrong manner.

Spare parts may be obtained from the outlet where the marquee was purchased. Please note that damage caused through adverse weather conditions, incorrect handling, accidental damage, misuse and improper packing and / or storage are not covered by the warranty.

Assembly Instructions.

The marquee should be erected on flat, level ground. We advise that you do not attempt to erect it on your own but obtain assistance, as this will make the job a lot easier.

Start by assembling the roof frame as per the instructions, making sure you use the correct poles, as using the wrong ones will mean the canopy will not fit properly. Once the frame is together, place the canopy over the frame and fix at the edges using the little bungee cords supplied.

Once you have the roof on, raise up one edge and insert the legs into the sockets. Make sure the holes in the legs are at the bottom.

We suggest that you attach the end curtains at this stage as this will mean you are not trying to attach them later when the marquee is at its full height.

Now you should lift the other edge and repeat the procedure.

Once you have the marquee up you can attach the sidewalls using the same bungee cords as you used for attaching the roof and peg them down. Then attach the feet plates to the ends of the legs. These have holes in them for you to put pegs through.

It may be necessary at this stage to use some tie downs to provide extra stability to the marquee in case the weather turns windy. These are available, for a small extra cost, from the outlet where you purchased the marquee. We strongly advise the use of these as, even though the weather may be nice when you put the marquee up, the wind can get up very quickly in this country and it's better to be safe than sorry. We recommend one tie down for every 2mtr length of marquee so, for example, a 6mtr long one would require 6, that's 3 a side, an 8mtr one 8 and so on.

VERY IMPORTANT

PLEASE READ CAREFULLY

This marquee IS NOT intended to be a PERMANENT STRUCTURE.

It is for OCCASIONAL use only and is not intended or designed to be used for commercial purposes or as a permanent structure or storage facility.

Any warranty will be voided if the structure has been used as such.

Any warranty will be voided if the structure has been left erected in adverse weather conditions such as strong winds, snow, hail etc.

You are strongly advised to take out some form of insurance to cover the marquee in the event of any damage occurring.



Nicoll Industries